



CONTROL PACKAGE



WWW.TUTTLEANDBAILEY.COM 1203 - 9/01

CONTROL PACKAGE 1203

CONTROL DIAGRAM



----- PRIMARY AIR FLOW

SEQUENCE OF OPERATION

1.) COOLING ONLY

Airflow is at minimum when thermostat branch pressure is above 8 PSIG. On a rise in room temperature, the thermostat branch pressure decreases to 3 PSIG and air flow increases to maximum. The reverse will occur, with a drop in room temperature.

2.) COOLING WITH REHEAT

Primary air flow is at minimum and the reheat is energized when thermostat branch pressure is between 8-13 PSIG. As room temperature increases reheat is sequenced off. With a further rise in room temperature the thermostat branch pressure decreases to 3 PSIG and primary airflow increases to maximum. The Reverse will occur with a drop in room temperature.

NOTE: Optional reheat control requires a normally closed hot water valve or normally open P/E switch.

3.) Damper fails open with loss of pneumatic air.

WWW.TUTTLEANDBAILEY.COM 1203P2 - 9/01